zoomphone

Configuration Guide for Fanvil ilx
Generic SIP Endpoints

Table of Contents

Table of Contents	2
Revision History	
1. Overview	3
2. Configuration Steps - Zoom Web Portal	3
3. Configuration Steps - Fanvil ilx Endpoint	6
4. Troubleshooting	8
5. FAQ	8
6. Resources	9

Revision History

Version	Date	Author	Change
1.0	23 Dec. 2022	Fanvil	Create configuration guide for Fanvil ilx



1. Overview

This section provides an overview for this document. This document provides instructions on how to configure and add your device to the Zoom Web Portal.

Fanvil ilx SIP Endpoints can register to Zoom Phone as a third-party SIP Endpoint and provide Telephony features and capability such as calling, paging and other phone system/PBX functions.

This configuration guidance is for Fanvil ilx (version: 2.4.8 and above).

2. Configuration Steps - Zoom Web Portal

This section provides instructions on how to configure SIP Endpoint in Zoom Web Portal (does not include steps for configuring Fanvil ilx Endpoint)

Prerequisites:


- Zoom Phone account: a valid Zoom Phone subscription is required in order to assign an Fanvil ilx endpoint.
- Zoom approval for provisioning of Fanvil ilx as Generic SIP devices. Administrators should contact Zoom Account Executive to start an approval process.

To register a SIP Endpoint to Zoom Phone, please start with creating a new common area phone in the Zoom Web Portal. For more information, please refer to the Zoom support site.

- 1. Sign in at the Zoom Web Portal
- 2. Click Phone system management > Users & Rooms
- 3. Click the Common Area Phones tab
- 4. Click Add and enter the following information
 - a. Display Name: Enter a display name to identify the device
 - b. Extension Number: Enter an extension number to assign it to the device
 - c. Package: Assign your device to a calling plan



Zoom Confidential




- 5. Click Save
- 6. At this point, navigate to Phone System Management → Phones & Devices tab
- 7. Press Add and enter the following information
 - a. Site(only visible if you have multiple sites): Select the site you want the device to belong to
 - b. Display Name: Enter a display name to identify the device
 - c. **Description**(optional): Enter a description to help you identify the location of the device
 - d. MAC Address: Enter the 12-digit MAC address of the Endpoint. The MAC can be found on the product label
 - e. Device Type: Select Other


Note: If you don't have the Other option, contact your Zoom sales representative. By default, supporting a generic SIP profile is not enabled

- f. Emergency Address (only visible if you don't have multiple sites): Select an emergency address to assign to the desk phone.
- g. Assigned to: choose a common area you want the device to belong to
- 8. Click Save






9. Click Provision to view the SIP credentials. It's required to complete the provisioning:










3. Configuration Steps - Fanvil ilx Endpoint

This section provides instructions on how to configure Fanvil ilx SIP Endpoint (does not include steps for configuring in Zoom Web Portal)

1. Topology diagram:



2. Collect IP address of Fanvil ilx:



Press and hold the speed dial button for 3 seconds, wait for the loudspeaker to beep quickly. Press the speed dial button three times within 5 seconds, and the system will automatically announce the IP address by voice after successfully switching to dynamic IP (Refer User manual in

https://www.fanvil.com/service/doc/file/p0/sipdj/i16si16sv/index.html)

- 3. Input SIP credentials for Fanvil ilx via Web UI interface
 - a. Tap the IP address (step 2) in the browser address bar and then press Enter. Input default username (admin) and password (admin) then click Login
 - b. Navigate to Line \rightarrow SIP. Under SIP1, please ensure the below parameters are set;

Line: SIP 1

Activate: Enable

Authentication User: input **Authorization ID** (SIP credential in 2.9) Authentication Password: input **Password** (SIP credential in 2.9)

User Name: input **Username** (SIP credential in 2.9) Display Name: input preferred name (example: Zoom)

In SIP server 1:

Server Address: input SIP Domain (SIP credential in 2.9)


Server Port: 5091

Transport protocol: TLS

Proxy Server Address: input Outbound Proxy remove port (SIP credential in 2.9)

Proxy Server Port: 5091

c. Click Apply and check Line Status is Registered



4. Setting the Speed Dial Function Key - Single button



Once the intercom is registered with Zoom, the "Speed Dial" function key will need to be set for the intercom to call a number when the front Call Button was pressed. This number can be either a direct extension, ring group/call queue, or a direct phone number.

a. After Logging into the intercom, go to the Function Key Tab.

b. Ensure the below parameters are set in the DSSKEY1 option:

Type: Memory Key

Value: the extension you want the intercom to call.

Subtype: Speed Dial

Line: choose the ZOOM registered SIP line.



4. Troubleshooting

1. For i16x latest firmware, Quick Installation Guide, User Manual,

Datasheet: https://www.fanvil.com/service/doc/file/p0/sipdj/i16si16sv/index.html

2. For i10x latest firmware, Quick Installation Guide, User Manual,

Datasheet: https://www.fanvil.com/service/doc/file/p0/sipdj/i10si10svi10sd/index.html

5. FAQ

For FAQ: https://www.fanvil.com/service/help/faq/security%20products-basic%20function/index.html



6. Resources

For contacting Fanvil technical support team, please send emails to $\frac{support@fanvil.com}{support@fanvil.com} \ or \\ log in to the Fanvil ticket system \\ \frac{https://www.fanvil.com/service/help/question.html}{support@fanvil.com} \ , \\ where our team is 24hrs fast reply during work days$

